MIDAS Service Information

September 2001

Internal Modifications on VENICE consoles

The console is designed to satisfy almost all applications. The internal modifications are offered to provide alternative routings for very special applications. All modifications can be carried out from the bottom side of the P.C.B..

Warning: The modifications involve cutting of traces and resoldering of specially designed pads and should only carried out by competent electronic technicians. MIDAS accepts no responsibility for any damages or injuries. In case of damages by modifications, MIDAS may declare warranty privileges void.

To open the unit, the following steps are necessary:

- 1. Remove all cords including the mains cord.
- 2. Remove the sidewings and the armrest.
- 3. Remove the screws that attach the top panel.
- 4. Open the top panel carefully. Now you have access to the bottom side of the P.C.B..

All modifications are possible by cut and solder the triple-pads as follows:

Mon and aux sends post-eq :

triple-pads called "MONAUX"

- cut track between centre pad and 'PRE_EQ' pad
- solder centre pad to 'POST_EQ' pad

Fx sends pre-fader:

triple-pads called "FX"

- cut track between centre pad and 'POST' pad
- solder centre pad to 'PRE' pad

Direct outs pre-fader:

triple-pads called "DIROUT"

- cut track between centre pad and 'POST' pad
- solder centre pad to 'PRE' pad



Direct Out Mon/Aux

